

XINNOR

Xinnor xiRAID 4.0.1 Command Reference

Contents

Xinnor xiRAID 4.0.1 Command Reference.....	5
Overview.....	5
Command Line Interface (CLI) Description.....	5
config.....	6
apply.....	6
backup.....	6
restore.....	7
show.....	7
drive.....	8
clean.....	8
faulty-count reset.....	8
faulty-count show.....	9
locate.....	10
license.....	10
delete.....	10
show.....	10
update.....	11
log.....	11
collect.....	11
show.....	11
mail.....	12
add.....	12
remove.....	13
show.....	13
pool.....	14
add.....	14
create.....	14
delete.....	15
remove.....	15

show.....	15
raid.....	16
create.....	17
destroy.....	20
import apply.....	20
import show.....	21
init start.....	21
init stop.....	22
modify.....	22
recon start.....	24
recon stop.....	25
replace.....	25
resize.....	26
restore.....	26
restripe continue.....	26
restripe start.....	27
restripe stop.....	27
show.....	28
unload.....	29
settings.....	29
auth modify.....	30
auth show.....	31
cpu-ignore modify.....	31
cpu-ignore show.....	31
eula modify.....	32
eula show.....	32
faulty-count modify.....	33
faulty-count show.....	33
log modify.....	34
log show.....	34
mail modify.....	35

mail show.....	35
pool modify.....	36
pool show.....	36
scanner modify.....	37
settings_scanner_show.....	38
update.....	38

Xinnor xiRAID 4.0.1 Command Reference

A list of commands and their descriptions.

Overview

Manage your software Xinnor xiRAID in Linux by using the `xicli` program.

The `eracli` managing program is still available, but deprecated and won't be supported in this the future releases of the program.

Command Line Interface (CLI) Description

Conventions on CLI command syntax

Item format	Description
item	A required item (command, subcommand, argument, option).
<item>	A placeholder variable.
[item]	An optional item.

In the CLI, enter commands in the following format:

```
# xicli <command> <subcommand> <required_args> [optional_args]
```

To show the full list of commands, run

```
# xicli -h
```

To show the `xicli` version, run

```
# xicli -v
```

CLI syntax specifics:

1. Type the arguments of the subcommands in one line.
2. Subcommand arguments are separated by spaces.
3. Use short or long forms of subcommand argument options.

4. To get the list of all subcommands and arguments, add the -h option:

```
# xicli <command> <subcommand> -h
```

A detailed description of the commands and subcommands is presented in the corresponding sections of the document.

config

Operations with the configuration file.

```
# xicli config <subcommand> <args> [optional_args]
```

Subcommands for the config command:

apply	Apply the configuration file for all restoring RAIDs.
-------	-------------------------------------------------------

backup	Save the current configuration file (create the backup file <code>backup_raid.conf</code> at the current directory).
--------	----------------------------------------------------------------------------------------------------------------------

restore	Restore the configuration file from a file or from the drives.
---------	----------------------------------------------------------------

show	Show configuration files stored on the drives.
------	------------------------------------------------

apply

Apply the current configuration file `/etc/xiraid/raid.conf` and restore all RAIDs with the status "None" from the file and delete all xiRAID RAIDs that are not in the file.

```
# xicli config apply
```

backup

Save the current configuration file (create the backup file `backup_raid.conf` at the current directory).

```
# xicli config backup
```

restore

Restore (if missing) or replace the configuration file without applying from a file or from the drives.

```
# xicli config restore <arg>
```

Arguments for the **restore** subcommand

Mutually exclusive required arguments

-f	--file	A file to restore the configuration file. If no file is specified, restore from /etc/xi-raid/raid.conf.bak.
-d	--drives	The list of block devices (/dev/sd*, /dev/mapper/mpath*, /dev/nvme*, /dev/dm-*) separated by a space to restore the configuration file to /etc/raid.conf.drive. If no block devices are specified, restore from all block devices.

show

Show configuration files stored on the drives.

```
# xicli config show [optional_arg]
```

Argument for the **show** subcommand

Optional argument

-d	--drives	The list of block devices (/dev/sd*, /dev/mapper/mpath*, /dev/nvme*, /dev/dm-*) separated by a space. Without the argument, show from all disks. The command also shows the newest configuration file from the drives.
----	----------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

drive

Operations with the drives.

```
# xicli drive <subcommand> <args> [optional_args]
```

Subcommands for the `drive` command:

clean	Delete the metadata and reset the number of failures from the drives.
-------	-----------------------------------------------------------------------

faulty-count reset	Reset the current number of failures for drives.
--------------------	--------------------------------------------------

faulty-count show	Show the current number of failures for drives.
-------------------	-------------------------------------------------

locate	Manage the drive LED indication.
--------	----------------------------------

clean

Delete the metadata and reset the fault counter from the drives.

```
# xicli drive clean <arg>
```

Argument for the `clean` subcommand

Required argument

-d	--drives	The list of block devices (/dev/sd*, /dev/mapper/mpath*, /dev/nvme*, /dev/dm-*) separated by a space to delete metadata and reset the fault counter.
----	----------	------------------------------------------------------------------------------------------------------------------------------------------------------

faulty-count reset

Reset the current numbers of failures for drives.

```
# xicli drive faulty-count reset <arg>
```

Arguments for the `faulty-count reset` subcommand

Required argument

Arguments for the `faulty-count reset` subcommand (continued)

-d	--drives	The list of block devices (/dev/sd*, /dev/mapper/mpath*, /dev/nvme*, /dev/dm-*) separated by a space to reset their current numbers of failures.
----	----------	--------------------------------------------------------------------------------------------------------------------------------------------------

faulty-count show

Show the current numbers of failures for drives.

```
# xicli drive faulty-count show [optional_args]
```

Arguments for the `faulty-count show` subcommand

Mutually exclusive optional arguments

-n	--names	The RAID name for which drives the current number of failures will be shown. If neither of the two arguments is specified, show the values for all drives.
-d	--drives	The list of block devices (/dev/sd*, /dev/mapper/mpath*, /dev/nvme*, /dev/dm-*) separated by a space to show their current numbers of failures. If neither of the two arguments is specified, show the values for all drives.

Optional argument

-f	--format	Output format: <ul style="list-style-type: none">• table;• json;• prettyjson – human-readable json. The default: table .
----	----------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

locate

Manage the drive LED indication.

```
# xicli drive locate <arg>
```

Argument for the `locate` subcommand

Required argument

-d	--drives	The list of block devices (/dev/sd*, /dev/mapper/mpath*, /dev/nvme*, /dev/dm-*) separated by a space to switch the indication on, or switch the indication off (with the null value). The argument doesn't affect the automatic indication.
----	----------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

license

Operations with the license.

```
# xicli license <subcommand>
```

Subcommands for the `license` command:

delete	Delete the current license.
show	Show info on the current license.
update	Update the current license.

delete

Delete the current license.

```
# xicli license delete
```

show

Show info on the current license.

```
# xicli license show
```

update

Update the current license.

```
# xicli license update <arg>
```

Argument for the `update` subcommand

Required argument

-p --path The path to the new license file.

log

Operations with the event log.

```
# xicli log <subcommand> <args>
```

Subcommands for the `log` command:

collect Collect the event log entries into a file.

show Show the last entries in the event log.

collect

Collect the event log entries into a file in /tmp.

```
# xicli log collect
```

show

Show the last error messages in the event log.

```
# xicli log show [optional_arg]
```

Argument for the `show` subcommand

Optional argument

Argument for the `show` subcommand (continued)

-l	--lines	The number of error messages in the event log to show, starting from the last entry. Possible values: integers from 1 to 1000. The default: 10.
----	---------	---------------------------------------------------------------------------------------------------------------------------------------------------------------

mail

Operations with the mail notifications.

```
# xicli mail <subcommand> <args> [optional_args]
```

Subcommands for the `mail` command:

add	Set the receiver's email and the notification level.
remove	Remove the email from the list of email notifications.
show	Show the list of the email notifications.

add

Set the receiver's email and the notification level.

```
# xicli mail add <args>
```

Arguments for the `add` subcommand**Required arguments**

-a	--address	Receiver's email.
-l	--level	The notification level. Possible values:

Arguments for the `add` subcommand (continued)

- **info** – Info notifications;
- **warning** – Error and Warning notifications;
- **error** – Error notifications.

remove

Remove the email from the list of email notifications.

```
# xicli mail remove <arg>
```

Argument for the `remove` subcommand

Required argument

-a	--address	The email address to remove from the notifications.
----	-----------	-----------------------------------------------------

show

Show the list of the email notifications.

```
# xicli mail show
```

Argument for the `show` subcommand

Optional argument

-f	--format	Output format: <ul style="list-style-type: none">• table;• json;• prettyjson – human-readable json.
----	----------	----------------------------------------------------------------------------------------------------------------------------------------------------------

The default: **table**.

pool

Operations with the spare pools.

```
# xicli pool <subcommand> <args> [optional_args]
```

Subcommands for the `pool` command:

add	Add drive(s) to the spare pool.
create	Create the spare pool.
delete	Delete the spare pool.
remove	Remove drive(s) from the spare pool.
show	Show info on the spare pool.

add

Add drive(s) to the spare pool.

```
# xicli pool add <args>
```

Arguments for the `add` subcommand

Required arguments

-n	--name	The name of the spare pool.
-d	--drives	The list of block devices (/dev/sd*, /dev/mapper/mpath*, /dev/nvme*, /dev/dm-*) separated by a space.

create

Create the spare pool.

```
# xicli pool create <args>
```

Arguments for the `create` subcommand

Required arguments

Arguments for the `create` subcommand (continued)

-n	--name	The name of the spare pool.
-d	--drives	The list of block devices (/dev/sd*, /dev/mapper/mpath*, /dev/nvme*, /dev/dm-*) separated by a space.

delete

Delete the spare pool.

```
# xicli pool delete <arg>
```

Argument for the `delete` subcommand

Required argument

-n	--name	The name of the spare pool.
----	--------	-----------------------------

remove

Remove drive(s) from the spare pool.

```
# xicli pool remove <args>
```

Arguments for the `remove` subcommand

Required arguments

-n	--name	The name of the spare pool.
-d	--drives	The list of block devices (/dev/sd*, /dev/mapper/mpath*, /dev/nvme*, /dev/dm-*) separated by a space.

show

Show info on the spare pool.

```
# xicli pool show [optional_args]
```

Arguments for the `show` subcommand

Optional arguments

-n	--name	The name of the spare pool. Without the argument, show info on all spare pools.
-f	--format	Output format: <ul style="list-style-type: none">• table;• json;• prettyjson – human-readable json.
-u	--units	Size units: <ul style="list-style-type: none">• s – sectors (1 sector=512 bytes);• k – kilobytes;• m – megabytes;• g – gigabytes. The default: g .

raid

Operations with the RAIDs.

```
# xicli raid <subcommand> <args> [optional_args]
```

Subcommands for the `raid` command:

create	Create the RAID.
destroy	Delete the RAID without possibility to restore the RAID and data on it.
import apply	Import (or restore) the RAID from drive metadata.

import show	Show info about the RAIDs that can be imported (restored) from the drives.
init start	Start or continue the RAID initialization.
init stop	Stop the RAID initialization.
modify	Modify the parameters of the created RAID.
recon start	Start the raid reconstruction.
recon stop	Stop the RAID reconstruction.
replace	Replace or remove the drive from the RAID.
resize	Change the RAID size.
restore	Restore the RAID from the drive metadata.
restripe continue	Continue the RAID restripe.
restripe start	Start the RAID restripe.
restripe stop	Pause the RAID restripe.
show	Show info about the RAID.
unload	Remove (unload) the RAID with possibility to restore the RAID and save data on it.

create

Create the RAID.

```
# xicli raid create <args> [optional_args]
```

Arguments for the `create` subcommand

Required arguments

-n	--name	The name of the RAID.
-l	--level	The level of the RAID: 0, 1, 5, 6, 7, 10, 50, 60, 70 , or nm .
-d	--drives	The list of block devices (<code>/dev/sd*</code> , <code>/dev/mapper/mpath*</code> , <code>/dev/nvme*</code> , <code>/dev/dm-*</code>) separated by a space.
-gs	--group_size	Only for RAIDs 50, 60, or 70.

Arguments for the `create` subcommand (continued)

The number of drives for one RAID group of level 5, 6, or 7.3 of the appropriate RAID 50, 60, or 70.

Possible values are integers from **4** to **32**.

-sc	--synd_cnt	Only for RAIDs N+M. The number of syndromes M. Possible values are integers from 4 to 32 . Additional conditions: N+M # 64 and M # N.
-----	------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Optional arguments

-bs	--block_size	RAID block size: 512 or 4096 bytes. The default: 4096 .
-inp	--init_prio	Except RAID 0. Initialization priority in %. Possible values are from 0 to 100 (maximum rate of initialization). The default: 100 .
-mwe	--merge_write_enabled	Except RAIDs 0, 1, 10. Enable (1) or disable (0) the Merge function for write operations. The default: 0 .
-mre	--merge_read_enabled	Except RAIDs 0, 1, 10. Enable (1) or disable (0) the Merge function for read operations. The default: 0 .
-ml	--memory_limit	RAM usage limit in MiB. Possible values: 0 and integers from 1024 to 1048576 . The 0 value sets unlimited RAM usage. The default: 0 .
-mm	--merge_max	Except RAIDs 0, 1, 10.

Arguments for the `create` subcommand (continued)

		Maximum wait time (in microseconds) for stripe accumulation for the Merge functions. Possible values: integers from 1 to 100000 . The default: 1000 .
-mw	--merge_wait	Except RAIDs 0, 1, 10. Wait time (in microseconds) between requests for the Merge functions. Possible values: integers from 1 to 100000 . The value must be less than the merge_max value. The default: 300 .
-rcp	--recon_prio	Except RAID 0. Reconstruction priority in %. Possible values are from 0 to 100 (maximum rate of reconstruction). The default: 100 .
-re	--resync_enabled	Except RAIDs 0, 1, 10. Enable (1) or disable (0) the Resync function. The default: 1 .
-rl	--request_limit	Number of simultaneous I/O requests on RAID. Possible values: from 0 (unlimited) to 4294967295 . The 0 value disables the restriction. The default: 0 .
-rsp	--restripe_prio	Restriping priority in %. Possible values are from 0 to 100 (maximum rate of restriping). The default: 100 .
-se	--sched_enabled	Enable (1) or disable (0) the scheduling function.

Arguments for the `create` subcommand (continued)

The default: 0.

-sp	--sparepool	Name of the spare pool to assign to the RAID.
-ss	--strip_size	Strip size in KiB. Possible values: 16, 32, 64, 128, or 256. The default: 16.

destroy

Delete the RAID without possibility to restore the RAID and data on it.

```
# xicli raid destroy <arg>
```

Arguments for the `destroy` subcommand

Mutually exclusive required arguments

-n	--name	The name of the RAID.
-a	--all	Delete all the xiRAID RAIDs. The argument takes no value.

import apply

Import (or restore) the RAID from drive metadata.

```
# xicli raid import apply <arg> [optional_arg]
```

Arguments for the `import apply` subcommand

Required argument

-id	--uuid	UUID of the RAID.
-----	--------	-------------------

Optional argument

-nn	--new_name	The new name for the RAID.
-----	------------	----------------------------

import show

Show info about the RAIDs that can be imported (restored) from the drives.

```
# xicli raid import show [optional_args]
```

Arguments for the `import show` subcommand

Optional arguments

-d	--drives	The list of block devices (/dev/sd*, /dev/mapper/mpath*, /dev/nvme*, /dev/dm-*) separated by a space to show the info. Without the argument, shows the info from all drives.
----	----------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

-f	--format	Output format: <ul style="list-style-type: none">• table;• json;• prettyjson – human-readable json.
----	----------	----------------------------------------------------------------------------------------------------------------------------------------------------------

The default: **table**.

--offline	Show non-recoverable RAIDs in the import list. The argument takes no value.
-----------	------------------------------------------------------------------------------------

init start

Start or continue the RAID initialization.

```
# xicli raid init start <arg>
```

Argument for the `init start` subcommand

Required argument

-n	--name	The name of the RAID.
----	--------	-----------------------

init stop

Stop the RAID initialization.

```
# xicli raid init stop <arg>
```

Argument for the `init stop` subcommand

Required argument

-n	--name	The name of the RAID.
----	--------	-----------------------

modify

Modify the parameters of the created RAID.

```
# xicli raid modify <arg> [optional_args]
```

Arguments for the `modify` subcommand

Required argument

-n	--name	The name of the RAID.
----	--------	-----------------------

Optional arguments

-inp	--init_prio	Except RAID 0. Initialization priority in %. Possible values are from 0 to 100 (maximum rate of initialization). The default: 100.
------	-------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------

-mwe	--merge_write_enabled	Except RAIDs 0, 1, 10. Enable (1) or disable (0) the Merge function for write operations. The default: 0.
------	-----------------------	-----------------------------------------------------------------------------------------------------------------------------------

-mre	--merge_read_enabled	Except RAIDs 0, 1, 10. Enable (1) or disable (0) the Merge function for read operations. The default: 0.
------	----------------------	----------------------------------------------------------------------------------------------------------------------------------

Arguments for the `modify` subcommand (continued)

-ml	--memory_limit	RAM usage limit in MiB. Possible values: 0 and integers from 1024 to 1048576 . The 0 value sets unlimited RAM usage. The default: 0 (unlimited).
-mm	--merge_max	Except RAID 0, 1, 10. Maximum wait time (in microseconds) for stripe accumulation for the Merge functions. Possible values: integers from 1 to 100000 . The default: 1000 .
-mw	--merge_wait	Except RAID 0, 1, 10. Wait time (in microseconds) between requests for the Merge functions. Possible values: integers from 1 to 100000 . The value must be less than the merge_max value. The default: 300 .
-rcp	--recon_prio	Except RAID 0. Reconstruction priority in %. Possible values: from 0 to 100 (maximum rate of reconstruction). The default: 100 .
-re	--resync_enabled	Except RAID 0, 1, 10. Enable (1) or disable (0) the resync function. The default: 1 .
-rl	--request_limit	Number of simultaneous I/O requests on RAID.

Arguments for the `modify` subcommand (continued)

		Possible values: integers from 0 to 4294967295 . The 0 value disables the restriction. The default: 0 .
-rsp	--restripe_prio	Restriping priority in %. Possible values are from 0 to 100 (maximum rate of restriping). The default: 100 .
-se	--sched_enabled	Enable (1) or disable (0) the scheduling function. The default: 0 .
-sp	--sparepool	Name of the spare pool to assign to the RAID. The null value removes the spare pool from the RAID. Spare pool can not be assigned to RAID 0.
	--force_online	Change RAID state to online if the RAID has unrecoverable sections. I/O operations on unrecoverable sections may lead to data corruption. The argument takes no value.
	--force_resync	Force RAID re-initialization. The argument takes no value.

recon start

Start the RAID reconstruction.

```
# xicli raid recon start <arg>
```

Argument for the `recon start` subcommand

Required argument

-n	--name	The name of the RAID.
----	--------	-----------------------

recon stop

Stop the RAID reconstruction.

```
# xicli raid recon stop <arg>
```

Argument for the `recon stop` subcommand

Required argument

-n	--name	The name of the RAID.
----	--------	-----------------------

replace

Replace or remove the drive from the RAID.

```
# xicli raid replace <args>
```

Arguments for the `replace` subcommand

Required arguments

-n	--name	The name of the RAID.
----	--------	-----------------------

-no	--number	The number of the drive.
-----	----------	--------------------------

To find out the number of the drive, use

```
# xicli raid show
```

-d	--drive	The new block device.
----	---------	-----------------------

To remove the drive (to mark it as missing) set the **null** value.

resize

Change the RAID size.

```
# xicli raid resize <arg>
```

Argument for the **resize** subcommand

Required argument

-n --name The name of the RAID.

restore

Restore the RAID from the current configuration file.

```
# xicli raid restore <arg>
```

Arguments for the **restore** subcommand

Mutually exclusive required arguments

-n	--name	The name of the RAID.
-a	--all	Restore all available xiRAID RAIDs. Argument takes no value.

restripe continue

Continue the RAID restripe.

```
# xicli raid restripe continue <arg>
```

Argument for the **restripe** subcommand

Required argument

Argument for the `restripe`**continue subcommand (continued)**

-n --name The name of the RAID.

restripe start

Start the RAID restripe.

```
# xicli raid restripe start <args>
```

Arguments for the `restripe start` subcommand**Required arguments**

-n --name The name of the RAID.
name

-l --level The new level for the RAID.

If you are only increasing the RAID size, enter the current RAID level for this argument.

-gs group_size The new group size for the RAID.

size
Possible values: integers from **4** to **32**.

-d --devices The list of block devices (`/dev/sd*`, `/dev/mapper/mpath*`, `/dev/nvme*`, `/dev/dm-*`) separated by a space to add to the RAID.

restripe stop

Pause the RAID restripe.

```
# xicli raid restripe stop <arg>
```

Argument for the `restripe stop`**subcommand****Required argument**

Argument for the `restripe stop` subcommand (continued)

`-n --name` The name of the RAID.

show

Show info about the RAID.

```
# xicli raid show [optional_args]
```

Arguments for the `show` subcommand

Optional arguments

<code>-n</code>	<code>--name</code>	The name of the RAID. Without the argument, show info on all xiRAID RAIDs.
-----------------	---------------------	-----------------------------------------------------------------------------------

<code>-o</code>	<code>--online</code>	Only show RAIDs that are in the “online” state (RAIDs that were not unloaded by the <code>raid unload</code> command). The argument takes no value.
-----------------	-----------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------

<code>-u</code>	<code>--units</code>	Dimension: • s – sectors (1 sector=512 bytes); • k – kilobytes; • m – megabytes; • g – gigabytes.
-----------------	----------------------	-----------------------------------------------------------------------------------------------------------------------------------------------

The default: **g**.

<code>-f</code>	<code>--format</code>	Output format: • table ; • json ; • prettyjson – human-readable json.
-----------------	-----------------------	---------------------------------------------------------------------------------------------------------

The default: **table**.

Arguments for the `show` subcommand (continued)

<code>-e</code>	<code>--extended</code>	Show extended output. The argument takes no value.
-----------------	-------------------------	-----------------------------------------------------------

unload

Remove (unload) the RAID with possibility to restore the RAID and save data on it.

```
# xicli raid unload <arg>
```

Arguments for the `unload` subcommand

Mutually exclusive required arguments

<code>-n</code>	<code>--name</code>	The name of the RAID.
<code>-a</code>	<code>--all</code>	Unload all available xiRAID RAIDs. The argument takes no value.

settings

Operations with the additional settings of the `xicli` program.

```
# xicli settings <subcommand> <args> [optional_args]
```

Subcommands for the `settings` command:

<code>auth modify</code>	Change client-server connection settings.
<code>auth show</code>	Show client-server connection settings.
<code>cpu-ignore modify</code>	Manage the CPU thread count control settings.
<code>cpu-ignore show</code>	Show the CPU thread count control settings.
<code>eula modify</code>	Manage the acceptance status of the EULA.
<code>eula show</code>	Show the acceptance status of the EULA.
<code>faulty-count modify</code>	Manage the threshold value of I/O errors for all drives.
<code>faulty-count show</code>	Show the threshold value of I/O errors.

log modify	Configure the type of system messages that will be added to the system log.
log show	Show the selected type of system messages for the system log.
mail modify	Manage email notification settings.
mail show	Show email notification settings.
pool modify	Manage delay timer (in seconds) for the drive replacement from the spare pools.
pool show	Show additional settings of the spare pools.
scanner modify	Manage RAID monitoring, the LED indication and drive SMART settings.
scanner show	Manage the LED indication and drive scan settings.

auth modify

Change client-server connection settings.

!

When you change any parameter of the settings auth modify command, the xiraid.target service restarts.

```
# xicli settings auth modify <args>
```

Arguments for the auth modify subcommand

At least one argument is required

--host	The host name or IP address that will be used for the connection. After changing the host, you must regenerate and replace the certificate.
--port	The port that will be used for the connection. The default: localhost .

auth show

Show client-server connection settings.

```
# xicli settings auth show
```

Argument for the `auth show` subcommand

Optional argument

-f

--format

Output format:

- **table**;
- **json**;
- **prettyjson** – human-readable json.

The default: **table**.

cpu-ignore modify

Select the CPUs that will not be used for the xiraid module.

```
# xicli settings cpu-ignore modify <arg>
```

Argument for the `cpu-ignore modify` subcommand

Required argument

--id

The list of CPU IDs (separated by a comma or a hyphen) that will not be used for xiraid.

The **null** value removes the restriction on using threads for xiraid.

cpu-ignore show

Show the list of CPUs that are not used for the xiraid module.

```
# xicli settings cpu-ignore show
```

Argument for the `cpu-ignore show` subcommand

Optional argument

-f

--format

Output format:

- **table**;
- **json**;
- **prettyjson** – human-readable json.

The default: **table**.

eula modify

Manage the acceptance status of the EULA.

```
# xicli settings eula modify
```

Argument for the `eula modify` subcommand

Required argument

-s

--status

The status of the EULA acceptance.

Possible values: **accepted**, **not_accepted**.

eula show

Show the acceptance status of the EULA.

```
# xicli settings eula show
```

Argument for the `eula show` subcommand

Optional argument

-f

--format

Output format:

- **table**;
- **json**;

Argument for the `eula show` subcommand (continued)

- `prettyjson` – human-readable json.

The default: `table`.

faulty-count modify

Manage the threshold value of I/O errors for all drives.

```
# xicli settings faulty-count modify <arg>
```

Argument for the `faulty-count modify` subcommand

Required argument

-t	--threshold	The threshold value for all drives. If you set a new fault threshold value, the current numbers of faults are reset for all the drives. Possible values: integers from 1 to 1000. The default: 3.
----	-------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

faulty-count show

Show the threshold value of I/O errors.

```
# xicli settings faulty-count show
```

Argument for the `faulty-count show` subcommand

Optional argument

-f	--format	Output format:
----	----------	----------------

Argument for the `faulty-count show` subcommand (continued)

- **table**;
- **json**;
- **prettyjson** – human-readable json.

The default: **table**.

log modify

Configure the type of system messages that will be added to the system log.

```
# xicli settings log modify <arg>
```

Argument for the `log modify` subcommand

Required argument

-l	--level	<p>The type of system messages that will be added to the system log. Possible values: error, warning, info, debug. Each next type includes the previous one. The default: debug.</p>
----	---------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

log show

Show the selected type of system messages for the system log.

```
# xicli settings log show [optional_arg]
```

Argument for the `log show` subcommand

Optional argument

-f	--format	Output format:
----	----------	----------------

Argument for the `log show` subcommand (continued)

- **table**;
- **json**;
- **prettyjson** – human-readable json.

The default: **table**.

mail modify

Manage email notification settings.

```
# xicli settings mail modify <args>
```

Arguments for the `mail modify` subcommand

At least one argument is required

-pi	--polling_interval	The polling interval for xiRAID RAIDs and the drives in seconds. Possible values: integers from 0 to 86400 (24 hours). The default: 10.
-ppi	--progress_polling_interval	Polling interval for the progress of initialization and reconstruction, in minutes. Possible values: integers from 0 to 1440 (24 hours). The default: 10.

mail show

Show email notification settings.

```
# xicli settings mail show
```

Argument for the `mail show` subcommand

Optional argument

-f

--format

Output format:

- **table**;
- **json**;
- **prettyjson** – human-readable json.

The default: **table**.

pool modify

Manage delay timer (in seconds) for the drive replacement from the spare pools.

```
# xicli settings pool modify <arg>
```

Argument for the `pool modify` subcommand

Required argument

-rd

--replace_delay

Delay time (in seconds) for the drive replacement from the spare pools.

Only one delay time is used for all the spare pools.

Possible values: integers from **1** to **3600**.

The default: **180**.

pool show

Show delay time used for the drive replacement from the spare pools.

```
# xicli settings pool show
```

Argument for the `pool show` subcommand

Optional argument

-f

--format

Output format:

- **table**;
- **json**;
- **prettyjson** – human-readable json.

The default: **table**.

scanner modify

Manage RAIDs monitoring, the LED indication and drive SMART settings.

```
# xicli settings scanner modify <args>
```

Arguments for the `scanner modify` subcommand

At least one argument is required

-pi

--polling_interval

The polling interval for xiRAID RAIDs and drives in seconds.

The parameter affects the auto-start delay for the RAID initialization, reconstruction, and restriping.

Possible values: integers from **1** to **3600** (1 hour).

The default: **1**.

-spi

--smart_polling_interval

S.M.A.R.T. drive health polling interval, in seconds.

Possible values: integers from **60** to **86400** (24 hours).

The default: **86400**.

Arguments for the `scanner modify` subcommand (continued)

-le	--led_enabled	Enable (1) or disable (0) the automatic LED indication of drives in the system. The default: 1. The argument doesn't affect manual LED indication.
-----	---------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------

settings_scanner_show

Show the LED indication and drive scan settings.

```
# xicli settings scanner show
```

Argument for the `scanner show` subcommand

Optional argument

-f	--format	Output format: • table ; • json ; • prettyjson – human-readable json. The default: table .
----	----------	--------------------------------------------------------------------------------------------------------------------------------------------

update

Operations with the Update Check service.

To check for an available update, run:

```
# xicli update check
```

Disable the Update Check Service to update Xinnor xiRAID 4.0.1 to a new availavle version.



Please, follow the instructions provided at xinnor.io to safely update your Xinnor xiRAID. Ignoring these steps may result in filesystem panick and even data loss.

To disable the Update Check Service, run:

```
# xicli update prepare
```



Please, do not run this command unless there is a new available Xinnor xiRAID version. Otherwise, the proper functioning of Xinnor xiRAID cannot be guaranteed.



The Update Check Service will inform you of any detected mounted xiRAID devices. Please, unmount the devices before continuing the update process.